

**Repair sequence**

- III. Remove condensate container from the dryer.
- IV. Replace old inner o-ring with new part:
  - a. Open the lid (1)
  - b. Press in the valve insert (2)
  - c. Remove inner o-ring (3) with pliers or a screwdriver
  - d. Remove valve insert and the spring (4) from the valve holder (5)
  - e. Manually remove any lint remainings from the spring and the valve insert
  - f. Rinse the spring and the valve insert with water
  - g. Manually remove any lint remainings from the inside of the valve holder
  - h. Rinse inside of the valve holder with water
  - i. Place the spring and valve insert back to the valve holder
  - j. Press in the valve insert
  - k. Assembly new inner o-ring onto the valve insert.
  - l. Close the lid
- VI. Replace old outer o-ring in condensate container with new part (6)
- VII. Replace old tray complete in bottom group with new part.
- VIII. Insert condensate container into the appliance.

